



**BRAKE PIPE SET 11 CV BN  
AF 52 - 52 ON**

**PS064060004**

---

**MONTAGE INSTRUCTIES:**

ALLE AANSLUITINGEN MOETEN SCHOON ZIJN, BUIG EN MONTEER DE REMLEIDINGEN VOLGENS DE SPECIFICATIES VAN DE AUTOFABRIKANT.

CONTROLEER DE REMLEIDINGEN NA MONTAGE EN WEES ER ZEKER VAN DAT ZE GEEN BEWEGENDE DELEN RAKEN.

SCHROEF DE REMLEIDING NIPPELS ER MET DE HAND OP, EN DRAAI ZE DAARNA ½ - 1 OMWENTELING VAST MET EEN SLEUTEL.

VUL EN ONTLUCHT HET SYSTEEM.

CONTROLEER UITEIDELIJK IEDERE AANSLUITING EN WEES ER ZEKER VAN DAT U EEN CONSTANTE HARDE REMPEDAALDRUK HEEFT, VOORDAT U MET DE AUTO DE WEG OP GAAT.

---

**FITTING INSTRUCTIONS:**

ALL CONNECTIONS MUST BE CLEANED, BEND AND FIT THE PIPES TO CAR MANUFACTURER SPECIFICATIONS.

CHECK PIPES AFTER FITTING AND MAKE SURE THAT THEY DO NOT CONTACT ANY MOVING PARTS. SCREW THE PIPE NUTS UP BY HAND FINALLY ADJUSTING WITH SPANNER A FURTHER ½ - 1 TURN. FILL AND BLEED THE SYSTEM.

FINALLY RECHECK EACH CONNECTION AND MAKE SURE THAT YOU HAVE A STABLE FIRM PEDAL PRESSURE BEFORE TAKING THE CAR ONTO THE ROAD.

---